

Thank you for the purchase of the Lloydz Primary Support Plate

**The use of this Support Plate will strengthen the Primary cover in the center area of the clutch's pull, thus reducing the flex that occurs with higher spring pressures.**

**You'll need a 3 & 4 mm Allen wrench and a small prying device for installation.**

- **Remove the 2 screws from the decorative cover, gently prying around the outer surface maybe needed to remove the cover.**
- **Next remove the 3 screws and the inner steel cover**
- **Clean excessive oil off the primary cover and your ready to install the Lloydz Support Plate.**
- **Make sure the O-Ring is clean and place it in the original position; a little grease will hold it in place if necessary.**
- **Install the Lloydz Support plate with the name as shown below. Use the 4 supplied screws to secure it in place.**
- **Tighten screws to 95 INCH POUNDS or 8 Ft Lbs.**

